

SDHC Compatibility Report



2007/3/28

Item	Manufacturer	Model Name	Type	TS4GSDHC150	TS4GSDHC6	TS8GSDHC6	TS4GSDMHC	Note*
1	CANON	Digital IXUS 900 Ti	Digital Still Camera	○	○	○	○	
2	CANON	Digital IXUS 850 IS	Digital Still Camera	○	○	○	○	
3	CANON	IXY DIGITAL 1000	Digital Still Camera	○	○	○	○	
4	CANON	IXY DIGITAL 900 IS	Digital Still Camera	○	○	○	○	
5	CANON	IXY DIGITAL L4	Digital Still Camera	○	○	○	○	
6	CANON	PowerShot A630	Digital Still Camera	○	○	○	○	
7	CANON	PowerShot A640	Digital Still Camera	○	○	○	○	
8	CANON	PowerShot A710 IS	Digital Still Camera	○	○	○	○	
9	CANON	PowerShot G7	Digital Still Camera	○	○	○	○	
10	CANON	PowerShot S3 IS	Digital Still Camera	○	○	○	○	
11	CANON	PowerShot SD900	Digital Still Camera	○	○	○	○	
12	CANON	PowerShot SD800 IS	Digital Still Camera	○	○	○	○	
13	CASIO	Exilm EX-S500	Digital Still Camera	○	○	X	○	Firmware v 1.01 → v 1.03
14	CASIO	Exilm EX-S600	Digital Still Camera	○	○	X	○	Firmware v 1.00 → v 1.01
15	CASIO	Exilm EX-S770	Digital Still Camera	○	○	X	○	
16	CASIO	Exilm EX-Z500	Digital Still Camera	○	○	X	○	Firmware v 1.00 → v 1.01
17	CASIO	Exilm EX-Z600	Digital Still Camera	○	○	X	○	Firmware v 1.01 → v 1.02
18	CASIO	Exilm EX-Z60	Digital Still Camera	○	○	X	○	
19	CASIO	Exilm EX-Z70	Digital Still Camera	○	○	X	○	
20	CASIO	Exilm EX-Z700	Digital Still Camera	○	○	X	○	
21	CASIO	Exilm EX-Z850	Digital Still Camera	○	○	X	○	Firmware v 1.00 → v 1.10
22	CASIO	Exilm EX-Z1000	Digital Still Camera	○	○	X	○	
23	NIKON	COOLPIX S5	Digital Still Camera	○	○	○	○	
24	NIKON	COOLPIX S6	Digital Still Camera	○	○	○	○	
25	NIKON	COOLPIX S7	Digital Still Camera	○	○	○	○	

Item	Manufacturer	Model Name	Type	TS4GSDHC15 0	TS4GSDHC6	TS8GSDHC6	TS4GSDMHC	Note*
26	NIKON	COOLPIX S10	Digital Still Camera	○	○	○	○	
27	NIKON	COOLPIX S50	Digital Still Camera	○	○	○	○	
28	NIKON	COOLPIX S200	Digital Still Camera	○	○	○	○	
29	NIKON	COOLPIX S500	Digital Still Camera	○	○	○	○	
30	NIKON	COOLPIX P5000	Digital Still Camera	○	○	○	○	
31	NIKON	D40	Digital Still Camera	○	○	○	○	
32	NIKON	D80	Digital Still Camera	○	○	○	○	
33	PANASONIC	DMC-FX07	Digital Still Camera	○	○	○	○	Maximum movie clip size 2 GB
34	PANASONIC	DMC-FX50	Digital Still Camera	○	○	○	○	Maximum movie clip size 2 GB
35	PANASONIC	DMC-FZ50	Digital Still Camera	○	○	○	○	Maximum movie clip size 2 GB
36	PANASONIC	DMC-L1	Digital Still Camera	○	○	○	○	Maximum movie clip size 2 GB
37	PANASONIC	DMC-L1K	Digital Still Camera	○	○	○	○	Maximum movie clip size 2 GB
38	PANASONIC	DMC-LX2	Digital Still Camera	○	○	○	○	Maximum movie clip size 2 GB
39	PANASONIC	SDR-S150	Digital Video Camera	○	○	○	○	
40	PANASONIC	SDR-S200	Digital Video Camera	○	○	○	○	
41	PANASONIC	SC-SX450/850	Audio Player	○	○	X	○	
42	PANASONIC	SD800N	Audio Player	○	○	X	○	
43	PANASONIC	SV-SD370V	Audio Player	○	○	X	○	
44	PENTAX	Optio A20	Digital Still Camera	○	○	X	○	
45	PENTAX	Optio E20	Digital Still Camera	○	○	X	○	
46	PENTAX	Optio M10	Digital Still Camera	○	○	○	○	
47	PENTAX	Optio M20	Digital Still Camera	○	○	○	○	
48	PENTAX	Optio S7	Digital Still Camera	○	○	X	○	
49	PENTAX	Optio T20	Digital Still Camera	○	○	X	○	
50	PENTAX	Optio W10	Digital Still Camera	○	○	○	○	
51	PENTAX	Optio W20	Digital Still Camera	○	○	○	○	
52	SANYO	Xacti DMX-CA6	Digital Still Camera	○	○	○	○	
53	SANYO	Xacti DMX-HD1A	Digital Still Camera	○	○	○	○	