


**Free PhotoRescue software CD is included with all Memory Corp's Standard and ProX Flash Cards**

PhotoRescue is a digital photo and data recovery solution for erased or damaged CompactFlash, Memory stick, XD, SmartMedia, SecureDigital, MultiMedia Cards and other media used for digital storage.



If your card is damaged, corrupted, or has been formatted, PhotoRescue is the best data-recovery solution you can get.

In 2001, PhotoRescue introduced the first affordable and fair "what you see is what you get" digital picture and digital photo data recovery solution. PhotoRescue will undelete, unerase and recover pictures, images, photos and files lost on corrupted, erased or damaged CompactFlash, Memory stick, XD, SmartMedia, SecureDigital, MultiMedia memory cards when other solutions fail. Unlike our competitors, we do guarantee our data recovery performance: once the demo previews your data, they will be recovered or you get your money back.

PhotoRescue supports the recovery of all file types but its algorithms are particularly optimized for JPG or JPEG files, TIFF files, GIFs and BMPs. It also offers a constantly updated support for CRW, NEF, ORF, MRW and many types of movie files. In some cases, we can even rebuild pictures that have suffered minor corruptions.

(RRP €12,-)